

## Fitting (see front cover)

Take an 8' length of dowel or similar (obtainable from your DIY store). Screw the enclosed cup hook into the end.



**FIXINGS (SCREW EYES)** supplied, are used here for top fixing into a plugged wall. They are also screwed into fascias or straight into the framework bottom, top and middle each side of conservatories. Always install bottom fixings first and try on shade to see exactly where top fixings and then middle should go.

**CORD**  
Thread cord through the knitted eyelets along the front of the shade leaving a foot (30cm) or so extra. Tie off at the corner eyelet at one end. Having put on the shade, make a cord loop under the end of each roof bar. At the far end pull taut and tie off at the other corner eyelet to prevent any lifting of the shade along the front.

**PUTTING ON THE SHADE**  
Unfold the shade and toss it onto the roof. Hook shade top, middle and bottom into fixings one end. Using a pole (with cup hook screwed in end) hook into spare top rubber tensioner loop. Walk around the conservatory, holding the shade aloft to clear any obstruction. Draw it up the roof. Hook onto fixings.



### ADJUSTABLE TENSIONERS (see front cover)

Loop through eyelets let into the shade each end. Pull the free end through the eye and pull hard into tension and pull outwards into slit. Press lock plug into adjacent vacant hole firmly (as illustrated). Reverse procedure for release.



# Koalashade Supashade



23 Wheatley Close, SAWBRIDGEWORTH, CM21 0HS  
**Tel: 07864 307759**  
**IF YOU HAVE ANY DIFFICULTY, SIMPLY RING**  
**[www.koalashade.co.uk](http://www.koalashade.co.uk)**